Technical Specs

EX1

F1

Codice: AV2981IN

Receiver

AV2981IN

Input Voltage:	12~48Vdc	Working Temp.:	-30℃~55℃
Output Voltage:	3~46Vdc	Dimensions:	L175×W44×H30(mm)
Output Current:	CC 350/700/1050mA×4CH	Package Size:	L178×W48×H33(mm)
Output Power:	1.05W~48.3W×4CH Max 193.2W	Weight(G.W.):	165g
Wireless Signal:	2.4GHz		

Note: Receiver is sold separately.

RoHS COMPLIANT warranty 5 years ISO9001:2008

Product Size:





AV2981IN

Installation Instruction:



Typical back box as below:





DMX Wiring:



RF Wireless Wiring:



Multi-control Wiring:



* After touch panel A realizes controlling the lamps, if B and C are matched up with A , they can also control the lamps.

* Connecting touch panel with DMX decoders can also realize multi-control function.

Match/Clear Code between Touch Panel & Receiver

Match code:

Method 1 : When the touch panel is on and the wiring between the receiver and the lamps are correctly,

1.

Power on the receiver, and complete step 2 within 10s.

2.

Long press ⏻ on the touch panel, the lamps begin flicker.

3.

Touch the slider in 5s, the lamps stop flicking, match successfully.

Method 2 : When the touch panel is on and the wiring between the receiver and the lamps are correctly,

1.



Short press "ID learning button" on the receiver.

2.

Long press ⏻ on the touch panel, the lamps begin flicker.

3.

Touch the slider in 5s, the lamps stop flicking, match successfully.

Clear code:

Method 1: Power on and off the receiver continuously for 5 times, If the buzzer long beep and lamps flicker twice, deactivate the matching successfully.

Method 2: Long press "ID learning button" on receiver for 5 seconds, If the lamps flicker twice, deactivate the matching successfully.

Match/Clear Code between Remotes:

Match code:

1.

Assuming that B match up with A.

2.

Long press ⏻ on the B, the indicator lights of 4 keys keep on after release.

3.

Touch the slider on A in 5s, when the indicator lights of B turn off, match successfully.

Clear code:

Long press the two keys ☾ ☽ on the touch panel B simultaneously (about 3 seconds) until the indicator light flicker several times, deactivate the matching successfully.

Match/Clear Code between Touch Panel & Remote:

Match code:

1.

Long press ⏻ on the touch panel, the indicator light of the four keys flicker.

2.



Long press ⏻ on the remote, the indicator light stop flicking, match successfully.

Clear code:

Long press the two keys ☾ ☽ on the touch panel simultaneously (about 3 second), if the indicator light flicker 3 times, deactivate.