







IR SENSOR SWITCH - S01

INSTALLATION

Please read the instruction sheet carefully before use!

GEN ERAL COMMENTS

is not liable for damages resulting from improper installation, improper use of elements of technical and non-compliance with this set of instructions.

- Keepthe instruction.
- Technical details are provided on the characterized label.
- PLEASE READ BEFORE INSTALLATION
- Switch is suitable for power supply 12VDC or 24VDC, made in the third class protection and marked designed for internal use only $\langle \cdot \rangle$.
- Mounting should be done according to the instruction.
- The thickness of the mounting location should not be higher than the specified length of the sensor assembly.
- To clean use only a soft, dry fabrics, do not use chemicals.
- Caution! During installation, the switch can not be connected to a power source.

INSTALLATION

- Gently take out the switch out of the packaging.
- Mark the switch installation position.
- The wires connecting the switch through the prepared hole / holes.
- Mount the switch demise of drawing 1A or 1B.
- Connect the 12VDC or 24VDC light source into the output circuit (cable with socket)
- Connect the 12VDC or 24VDC power supply to the power input cable (cable with plug).
- Ensure that all electrical connections and mounting are made properly it means so as to exclude faulty operation
- During the installation of furniture take special care not to damage the electrical insulation.

TECHNICAL SPECIFICATIONS

Input / output voltage	12 VDC / 24VDC		
The maximum controller load power	24W / 48W		
Sensor dimensions (diameter mounting / installation length)	15,6-16,8mm		
Switch dimensions (width x height x length)	17mm x 53mm		
Wire length (from the sensor to the plug)	1m		
Wire length (from the sensor to the socket)	1m		

Mode switch:

Mode 1 - SWITCH IR MONO - button to the right Close prevent the sensor turns off the receiver, oddalenieprzeszkody from the sensor switches on the receiver.

Mode 2 - SWITCH IR BI - the button to the left


The first close-up obstacles to the sensor will activate the receiver. Holding the obstacles to the sensor turns off the receiver.


- The product marked with an cross out trash can needs special treating with used electrical equipment.

Products marked with this sigh cannot be thrown away to the trash.

- Products with this sign can be dangerous to the environment, and they require special utilization and neutralization Further product transfer to utilization works, helps to save the environment

- More information about utilization and recycling can be received in the City Department or in the producer





IR SENSOR SWITCH - S01 INSTALLATION

Please read the instruction sheet carefully before use!

GEN ERAL COMMENTS

- is not liable for damages resulting from improper installation, improper use of elements of technical and non-compliance with this set of instructions.
- Keepthe instruction.
- Technical details are provided on the characterized label.
- PLEASE READ BEFORE INSTALLATION
- Switch is suitable for power supply 12VDC or 24VDC, made in the third class protection and marked designed for internal use only ().
- Mounting should be done according to the instruction.
- The thickness of the mounting location should not be higher than the specified length of the sensor assembly.
- To clean use only a soft, dry fabrics, do not use chemicals.
- Caution! During installation, the switch can not be connected to a power source.

INSTALLATION

- Gently take out the switch out of the packaging.
- Mark the switch installation position.
- The wires connecting the switch through the prepared hole / holes.
- Mount the switch demise of drawing 1A or 1B.
- Connect the 12VDC or 24VDC light source into the output circuit (cable with socket)
- Connect the 12VDC or 24VDC power supply to the power input cable (cable with plug).
- Ensure that all electrical connections and mounting are made properly it means so as to exclude faulty operation
- During the installation of furniture take special care not to damage the electrical insulation.

TECHNICAL SPECIFICATIONS

Input / output voltage	12 VDC / 24VDC		
The maximum controller load power	24W / 48W		
Sensor dimensions (diameter mounting / installation length)	15,6-16,8mm		
Switch dimensions (width x height x length)	17mm x 53mm		
Wire length (from the sensor to the plug)	1m		
Wire length (from the sensor to the socket)	1m		




Mode 1 - SWITCH IR MONO - button to the right Close prevent the sensor turns off the receiver,

oddalenieprzeszkody from the sensor switches on the receiver.

Mode 2 - SWITCH IR BI - the button to the left The first close-up obstacles to the sensor will activate the receiver. Holding the obstacles to the sensor turns off the receiver.

- The product marked with an cross out trash can needs special treating with used electrical equipment.
- Products marked with this sigh cannot be thrown away to the trash.
- Products with this sign can be dangerous to the environment, and they require special utilization and neutralization
- Further product transfer to utilization works, helps to save the environmen
- More information about utilization and recycling can be received in the City Department or in the producer





Carefully! Installation and connection to the mains power should only be carried out by qualified person with appropriate qualifications due to the existing risk of electric shock.

ENVIRONMENT PROTECTION:





Э)

JUILIO

TUGNI

Technical data


Æ

Z m MINI KONEKTOR

Sterne Sterne

Echnical data






SHor

0Zdl

 $\langle \! | \rangle$

X

mm 410



mm 410

Material	SnoiznamiQ	Color	le
Plastic	mm 53 x mm 410	Black	C
Plastic	mm £2 x mm 4tQ	ətirlW	C

Material	Dimensions	Color
Plastic	mm 53 x mm 410	Васк
Plastic	mm 53 x mm 41Q	əjidW